



P.O. Box 578
Enumclaw, WA 98022-0578
Phone: 360.825.6500
Fax: 360.825.6512

Instructions for Installing POLARIS PRO RIDE GAUGE CAGE

FITS:

Polaris Pro-Ride

Safety Warning: Carefully read and fully understand installation instructions before attempting to and installing any component on your snowmobile. Installation of any component should only be performed by someone experienced and familiar with the proper installation and operation of snowmobile parts. It is the sole responsibility of the installer to make certain the installation is done correctly and safely. Failure to do so can result in personal injury and/or property damage.

Installation Instructions:

1. Remove the side pods from each side of sled.
2. Remove windshield (pull pushpins).
3. **Remove hood by:**
 - a. Remove (2) bolts holding plastic cover next to steering post,
 - b. Pull (2) push pins on each side of hood,
 - c. Now raise REAR hood up a few inches, reach inside and unplug wiring harness.
 - d. Raise hood up and slide forward to release from front hinge.
4. **Remove headlight assembly:**
 - a. (2) bolts inside of hood next to light bulbs and
 - b. (1) bolt located on the outside, (center of hood under windshield strip).
5. **Remove the speedometer:**
 - a. Gently wiggle it out of hood. A rubber sleeve holds it in.
6. **Install Speedometer into Cage:**
 - a. Wiggle the speedometer and sleeve into Gauge Cage, (**MAKE SURE ITS NOT UPSIDE DOWN**). It's supposed to be a rather tight fit.
 - b. If needed apply some silicone spray on the rubber sleeve to aid installation.
7. **Fasten Gauge Cage to hood:**
 - a. Position cage over hole in hood fasten from the inside, using supplied bolts and fender washers. (Adjust for straightness before tightening down all the way).
 - b. (**MAKE SURE ITS NOT UPSIDE DOWN, ANGLED UP FOR STANDING RIDER**).
8. Now reassemble head light, plug in wiring, install hood and side pods.

Enjoy your new AMP product and ride safe !